



## **ZONEswitch INFRARED REMOTE CONTROL SETUP & TV CODES**

### **SET-UP PROCEDURE**

#### **ZONEswitch mode :**

Select RC5 System Code

- 1) ZS + Mute (keep pressing for 3 seconds : LED on).
- 2) press two digit (01-64) (This is preset to code 6 in web browser)
- 3) LED will blink 3 times and off.

#### **TV mode : code entry**

- 1) Press TV + Mute together
- 2) enter 3 digit code from list
- 3) LED will blink 3 times and off.

#### **TV : Auto-scan**

Remark : Auto-scan may also be used if TV brand code cannot be identified from list.

Please be patient as this method can take many, many button presses.

- 1) Press TV+ Mute together
- 2) Repeat pressing TV button (transmits POWER signals) until TV turns off.
- 3) Press MUTE (LED blink 3 times and off)
- 4) Check that pressing the red power button turns TV on again. \*\*\*

\*\*\* If TV does not turn on again repeat steps 1) & 2) above and then press "-" button (left-hand curser) once" before repeating step3) above.

ADMIRAL	302 333 350 391 399 461 538
ADYSOM	417 418
AGB	478
AIKO	302 393 417 418
AKURA	375
ALBA	375 379 399 417 418 462 465
ALBIRAL	312 399 419 420 512
ALLORGAN	417 418
AMSTRAD	302 353 354 391 468
ANAM	356
ANGLO	302
ANITECH	302 312
ANITECH	
ARC EN CIEL	341 448
ARC EN CIEL	
ARCAM	341 417 418 448 452 541
ARE EN CIEL	345 365 434
ARISTONA	305 306 312
ARTHUR MARTIN	309 350 399
AS-BERG	312
ASA	323 333 342 343 350 399 407
ASA	410 414 489 538
ASBERG	312 328
ASUKA	375 391 417 418
ATANTIC	312 417 452
ATLANTIC	417 418 452
ATORI	302
AUDIOSONIC	312 455
AUDIOTON	302 417 418
AUSIND	327 328 368 392
AUTOVOX	327 328 332 333 343 350 369
AUTOVOX	392 407 414 417 418 420
AUTOVOX	505 506 542
BAIRD	325 345 370 399 461 462
BANG & OLUFSON	333
BARCO	333 434 498
BASIC LINE	375
BAUER	321
BAUR	309 350 360 399
BAZIN	350 417 418 492
BEKO	530
BEON	312
BESTAR	312
BIGSTON	302 391

BINATONE	417 418
BLAUPUNKT	360 363 474 501 503 540 546
BLAUPUNKT	547 548 551
BONDSTEC	420
BOOTS	417 418
BRANDT	341 345 365 400 432 433 434
BRION VEGA	301 333 527 528
BRIONVEGA	312 332 333
BRITANNIA	417 418 452
BRUNS	333 409 538
BSR	302 309 350 399 406 461 462
BUSH	309 311 312 323 329 350 358
BUSH	375 379 399 461 465 468 469
BUSH	537
BUSH(UK)	350 414
CANDLE	318
CATHAY	312
CENTURY	333 420 538
CGE	302 309 327 328 350 356 392
CGE	398 399 420 435 453 461 462
CGE	474 475 476 477 491 507 542
CGE	544 549 550
CIMLINE	302 379
CITIZEN	313 318
CLARIVOX	333 409 416 419 486
CLATRONIC	328 375 391 417 418 420 455
CLATRONIC	530
CONCERTO	318
CONCORDE	302
CONDOR	302 312 392 417 418 452 513
CONDOR	530
CONTEC	302 349 356 358 406 417 418
CONTINENTAL EDISON	341 345 365 400 432 433 434
CONTINENTAL EDISON	448
CRAIG	356
CROSLEY	327 328 333 350 392 399 420
CROSLEY	461 462 474 475 476 477 491
CROSLEY	538
CROWN	302 313 328 363 375 530
CRYSTAL	312
CS ELECTRONIC	417 418 420 542
CTC	420
CTC CLATRONIC	312 340 375 420 512
CTV EXQUISIT	312

CXC	356
CYBERTRON	375
DAEWOO	302 312 313 375 417 418 469
DAEWOO	520
DAINICHI	375
DANSAI	312 391
DAYTRON	302 313
DECCA	304 325 382 383 395 416 417
DECCA	418 449 478 490 536
DECCA(UK)	325 417 418 449 300
DEGRAAF	315 350 370 399 461
DESMET	513
DIXI	302 312 409
DTS	302
DUAL	302 309 312 350 387 399 412
DUAL	417 418 479
DUAL-TEC	309 417 418
DUMONT	312 323 331 333 340 342 343
DUMONT	350 392 399 407 410 461 462
DUMONT	538
DYNATRON	312
ELBE	350 399 404 416 417 418 419
ELBE	499 500 504 543
ELECTROHOME	313
ELEKTRONSKA	416 422
ELIN	302 342 350 417 418
ELITE	312 375
ELMAN	309 340 399
ELTA	302 461
EMERSON	313 325 333 354 355 356 357
EMERSON	513
ERRES	305 312
ETRON	350 399
EUROMAN	417 418
EUROPHON	309 340 399 416 417 418 420
EUROPHON	422 449 536 542
FENNER	302
FERGUSON	301 319 326 345 350 359 400
FERGUSON	407 419 444 446 454 455
FIDELITY	326 330 350 390 399 417 418
FIDELITY	452 461
FIDELITY(UK)	350 447 450
FILSAI	417 418
FINLANDIA	343 350 370 399

FINLUX	312 323 327 328 331 333 340
FINLUX	342 343 350 368 399 407 410
FINLUX	414 430 435 453 461 538
FIRST LINE	302 312 350 399 415 417 418
FIRST LINE	542
FISHER	333 342 345 350 358 370 399
FISHER	409 412 417 418 428 461 462
FISHER	482 530 538
FLINT	312
FORMENTI	312 321 327 328 333 350 392
FORMENTI	399 417 418 452 513 538
FORMENTI-PHOENIX	350 368 399 450
FORTRESS	333 334 538
FRONTECH	302 350 391 399 420 455 461
FRONTECH	462 542
FRONTTECH	302
FUJITSU	325 350 355 461 505 539
FUNAI	302 355 356 391 406 412 455
FUNAI	539
FUTURETECH	356
GBC	302 309 350 358 375 399 461
GBC	462
GEC	312 314 325 350 399 416 417
GEC	418 461 464 478 536
GEC(UK)	309 314 325 350 399 417 418
GEC(UK)	449
GELOSO	302 309 350 375 399 420 542
GENERAL TECHNIC	302
GENEXXA	350 375 399 461
GIUCAR	515
GOLDSTAR	300 302 309 312 313 318 343
GOLDSTAR	350 387 399 403 409 417 418
GOLDSTAR	420 436 442 450 452 542
GOODMANS	309 311 312 325 350 358 386
GOODMANS	403 468 469
GORENJE	312 511
GPM	302 375
GRAETZ	350 399
GRANADA	305 311 312 325 327 328 347
GRANADA	350 358 368 370 399 416 417
GRANADA	418 449 461 478 487
GRANADA(UK)	328 350 358 377 399 417 418
GRANADA(UK)	449
GRANDIN	541

GRIFFIN	413
GRUNDIG	320 323 324 327 328 360 363
GRUNDIG	368 400 414 458 540
HALIFAX	391 417 418
HAMPTON	417 418
HANSEATIC	312 350 358 450 513 538
HANTAREX	312 416 449
HEMMERMANN	350 399
HIFIVOX	345 365 434 448
HIGASHI	417 418
HINARI	302 309 311 350 355 358 370
HINARI	375 399 461
HINART	539
HISAWA	333
HISAWA	375
HITACHI	309 311 314 315 316 336 337
HITACHI	343 345 350 356 358 362 364
HITACHI	365 366 376 384 399 400 417
HITACHI	418 437 451 457 463 464 466
HYPER	302 309 375 417 418 420 450
HYPSON	523
ICE	312 375 391 417 418
IMPERIAL	309 327 328 350 392 399 420
IMPERIAL	435 453 474 475 476 491 507
IMPERIAL	542 550
INGERSOL	302
INNO HIT	302 312 325 328 375 403 417
INNO HIT	418 449 478
INNOHIT	302 325 350 403 416 417 418
INNOHIT	420
INNOVATION	312 563
INTERBUY	302 420
INTERFUNK	305 309 312 328 333 345 350
INTERFUNK	399 443 538
INTERVISION	309 312 417 418 420 518 519
IRRADIO	302 312 327 328 368 375 392
IRRADIO	403 436 441
ISUKAI	375
ITC	417 418
ITS	312 375 468
ITT	309 311 327 328 342 350 370
ITT	379 399 443 456 462 463 467
ITT	469
ITT-NOKIA	309 311 328 342 350 370 379

ITT-NOKIA	399 443 456 469 494
JET POINT	312
JOHNSON	417 418
JVC	311 317 322 335 345 358 399
KAISER	312 375 417 418 450 524 525
KAMOSONIC	417 418
KAPSCH	342
KARCHER	312 343 350 417 418 450
KATSUI	375
KAWA	312
KAWASHO	417 452
KENDO	302 340
KENNEDY	326 350 399 461 462 499
KINSLEY	417 418
KNERSSEI	543
KOENIG	399
KOLSTER	512
KONKA	468
KORTING	333 401 538
KTV	313 356 417 418
KYOTO	399 461 462
LENCO	350 520
LENOIR	302 417 418
LESA	420 542
LEYEO	455
LIFETEC	302 312 391 563
LLOYTRON	313
LOEWE OPTA	312 333 402 416 449 478 536
LOEWE OPTA	538
LOGIK	446
LUMA	312 350 399
LUXMAN	318
LUXMAN STEREO TUNER	318
LUXOR	309 328 350 362 370 399 403
LUXOR	417 418 443 462 466
LUXOR SKANTIC	309 343 350 362 370 436
LYCO	391 455
M.ELECTRONIC	302 342 343 350 410 412 420
M.ELECTRONIC	430 520
MAGNADYNE	302 309 312 333 340 350 399
MAGNADYNE	416 420 422 449 510 536 538
MAGNADYNE	542 327 328 340 350 392 416
MAGNAFON	417 449 450 452 417 418 536
MANESTH	312

MARANTZ	312
MARECH	513
MARELLI	333 538
MARK	312
MATSUI	302 312 325 350 354 358 371
MATSUI	379 399 417 418 464 465 468
MAXIMAL	350
MAXIMAL	399
MCMICHAEL	314
MEDIATOR	312
MEMOREX	302
MEMPHIS	302 325
METZ	333 360 363 380 397 408 459
METZ	489 522 538 540
MGA	348
MICROMAXX	312 563
MINERVA	323 324 327 328 360 363 368
MINERVA	414
MITSUBISHI	302 304 308 311 312 333 344
MITSUBISHI	348 358 360 363 367 373 461
MIVAR	327 328 403 404 414 416 417
MIVAR	418 421 422 449 450 452 536
MULTITECH	302 340 416 417 418 420 449
MULTITECH	461 478 512 536 542
MURPHY	342 350 399 461
MURPHY(UK)	399
NAD	351
NAGEL	521
NATIONAL	377
NEC	302 311 352 358 488
NECKERMANN	312 333 350 360 399 417 418
NECKERMANN	538 553 554 555
NEI	312
NESCO	420
NEWTECH	417 418
NICAMAGIC	417 418 452
NIKKAI	307 309 310 312 325 350 355
NIKKAI	375
NOBIKO	327 328 340 368 392 414 417
NOBIKO	418 420 450
NOGAMATIC	345 365 434 448
NOKIA	309 311 328 342 350 370 379
NOKIA	399 443 456 461 462 467 469
NOKIA	560 300 300 300 300 300 300

NORDMENDE	309 317 332 341 345 350 364
NORDMENDE	365 366 399 400 411 423 425
NORDMENDE	434 445 448 457 462
OCEANIC	350 370 372 374 399 541
OCEANIC(F)	309 399
ONCEAS	417
ONCEAS	418
ONWA	356 524
OPTONICA	334
ORAVA	312
ORBIT	312
ORION	302 304 312 350 354 379 391
ORION	399 406 408 415 462 465 514
ORITRON	426
OSAKA	307 406
OSAKI	307 325 375 386 391 417 418
OSUME	325 349
OTTO VERSAND	311 350 358 359 360 399 417
OTTO VERSAND	418
OXFORD	424
PACE	556
PAEL	328 368 392 417 418 450
PALLADIUM	507
PANAMA	302 391 417 418
PANASONIC	309 346 350 373 377 378 384
PANASONIC	394 396 399 439 440 460 461
PANASONIC	463
PATHE CINEMA	399 417 418 497 513 541
PATHE MARCONI	341 345 365 400 432 433 434
PATHE MARCONI	448
PATHE CINEMA(F)	309 419 450
PAUSA	302
PERDIO	325
PERDIO	393
PHILEX	326 350
PHILICO	538 542
PHILIPS	305 306 312 314 333 385 404
PHILIPS	405 417 418 450 452 469 483
PHILIPS	484 485 487 493 495 538 552
PHOENIX	312 333 399 462 538
PHONOLA	305 306 312 333 405 417 418
PHONOLA	483 485 487 493 538
PIONEER	312 345 350 351 399 400 461
PORTLAND	313

PRANDONI-PRICE	327 350 416 420
PRANDONI-PRINCE	328 350 368 399 416 420 449
PRANDONI-PRINCE	536 542 328 399 449
PRIMA	302 350 399 461 462 325
PROFEX	302 350 399
PROLINE	415 300
PROTECH	302 312 340 350 391 399 417
PROTECH	418 420 455 461 462 464 542
PROTON	313
PYE	305 312 487
QUELLE	304 309 312 323 324 327 328
QUELLE	342 343 350 356 360 363 368
QUELLE	392 399 403 407 410 414 417
QUELLE	418 420 474 475 476 547 548
QUELLE	549 550 551
RADIOLA	305 312 495
RADIOMARELLI	302 312 333 350 367 399 416
RADIOMARELLI	420 422 510 538
RADIONETTE	309 342 343
RANK	323 414
RBM	323 329 537
RBM(UK)	414
REDIFFUSION	350 367 399 461 462
REDIFFUSION(UK)	399
REMOTE CONTROL UNIT	427
REX	350 369 387 399 505 506
RFT	409 531 532 533 534 535
ROADSTAR	302 375 391
ROBOTRONE	333
ROWSONIC	417 418
SABA	333 341 345 350 364 365 366
SABA	399 400 411 416 423 425 434
SABA	445 448 449 457 536 538 557
SACCS	419
SAIKOU	386
SAISHO	302 304 308 350 354 379 388
SAISHO	391 399 417 418 461 462
SALORA	309 350 362 370 399 456 461
SALORA	462 464 467
SAMBERS	327 328 340 368 392 403 416
SAMBERS	449 536 302 307 312 325 354
SAMSUNG	391 403 417 418 428 431 441
SAMSUNG	455 482 530 553
SANKYO	313

SANSUI	312
SANYO	304 311 316 325 333 342 343
SANYO	347 349 358 370 409 417 418
SANYO	456 482 494 300
SBR	305 306 312 314 385
SCHAUB LORENZ	350
SCHAUB LORENZ	399
SCHNEIDER	302 305 309 312 319 343 350
SCHNEIDER	375 387 399 412 417 418 450
SCHNEIDER	495 543
SCOTT	313 355 356
SEG	340 409 417 418 420 512 300
SEI	333 340 350 354 399 406 408
SEI	538
SEI-SYNUDINE	312 333 350 354 379 399 406
SEI-SYNUDINE	408
SELECO	345 350 369 387 399 480 496
SELECO	505 506 543
SENTRA	309 544
SHARP	311 334 349 358 481 509 516
SHARP	526
SHIVAKI	312
SIAREM	333 340 350 399 416 449 536
SIAREM	538
SICATEL	419
SIEL	312 328
SIEMENS	349 350 360 363 399 474 501
SIEMENS	540 546 547 548 551
SIERRA	305 375
SILVER	375 455 537
SINGER	302 333 340 350 420 538 542
SINUDYNE	333 340 350 354 379 399 406
SINUDYNE	408 538
SKANTIC	309 350 399 461 466
SOLAVOX	307 309 350 399 461
SONOKO	302 312 391 417 418 455
SONTEC	312
SONY	303 304 311 338 357 358 488
SONY	508 517 529
SOUNDESIGN	356
SOUNDWAVE	312
SSS	356
STANDARD	302 375 417 418 420 513 350
STERN	369 387 399 505 506

SUNKAI	406 415
SUPRA	302
SUPRA	318
SYDNEY	417 418
TANDBERG	333 345 365 392 414 459 325
TANDY	334 350 375 398 399 417 418
TANDY	420 461 542 544
TASHIKO	311 314 358 417 418
TATUNG	304 325 383 416 417 418 449
TATUNG	478 490 536
TCM	312
TEAK	312
TEC	302 350 417 418
TECHNICA	375
TECHNICS	377
TECHWOOD	318
TELEAVIA	341 345 365 400 432 434 448
TELEAVIA	433
TELEFUNKEN	301 317 326 339 345 356 365
TELEFUNKEN	389 400 425 438 446 470 471
TELEFUNKEN	472 473 474 475 476 477 478
TELEFUNKEN	479 549 550
TELEOPTA	302
TELETECH	302 420
TELETON	399 417 418 461 462
TELEVIDEON	350 392 417 418 513
TENSAI	302 312 342 375 469
TEXET	417 418
THOMSON	317 332 336 341 345 364 365
THOMSON	366 379 392 400 411 414 425
THOMSON	429 432 433 434 448 451 457
THORN	331 342 359 361 363 475 476
THORN	477
THORN-FERGUSON	319 326 344 345 359 400 407
THORN-FERGUSON	419 444 454 455 502
TMK	318 358 389
TOKAI	312 325
TOSHIBA	310 311 323 328 358 368 381
TOSHIBA	414 562
TOTEVISION	313
TOWADA	399 461 464
TRANS CONTINENS	350 399 350 416
TRIUMPH	331 354 368 414 416 449 478
TRIUMPH	536

UHER	327 328 350 377 399 412 414
UHER	513
ULTRAVOX	309 312 328 342 343 350 356
ULTRAVOX	363 368 392 399 410 414 420
ULTRAVOX	455 542 547 548 549 550 551
UNIVERSUM	304 312 328 342 343 350 356
UNIVERSUM	363 368 392 399 410 414 420
UNIVERSUM	455 542 547 548 549 550 551
UNIVOX	419
UTAX	417 418
UTHER	412
VEGAVOX	453
VESTEL	312 399 461 462
VEXA	302 312
VICTOR	317
VIDEOLGIC	375
VIDEOTON	350 417 418
VIDION	302
VISA ELECTRONICS	399 417 418
VISION	312
VORTEC	312 400
VOXSON	312 327 328 333 350 399 461
WALTHAM	399 417 418 466 544
WATSON	312 474 513
WATT RADIO	340 350 399 417 418 419 450
WATT RADIO	452 461 462 350 417 418
WEGA	311 333 350 358 399 538
WEGA COLOR	333 358 513
WEGAVOX	302
WELTBlick	312
WESTON	309
WHITE WESTINGHOUSE	340 417 418 450 452 461 399
WHITE- WESTINGHOUSE	417 418 513
YOKO	312 391 417 418
YORX	375
ZAMPA	309
ZANUSSI	350 369 399 461
ZOPPAS	350 399